

## MOUNTING INSTRUCTIONS: WALL MOUNT SWING OUT RACK RFM-1918-RWS-ADJ

RFM-1918-RWS-ADJ Parts List		
Item #	Qty	Part Description
1	1	RFM-1918-RWS Side 1
2	1	RFM-1918-RWS Side 2
3	2	RFM-1918-RWS RH Support 1
4	1	RFM-1918-RWS Support 2
7	1	RFM-1918-RWS Welded Rack Assembly
10	1	RFM-1918-RWS Bracket 3
11	2	RFM-1918-RWS Bracket 2
12	1	RFM-1918-RWS LH Support 1
13	5	1/4-20 X 3/4" Carriage Bolt
14	22	1/4-20 Keps Nut
15	19	1/4-20 X 3/4" Round Combo Head Screw
16	1	RFM-RWS Hinge

**Note:**

Items #1, 3, & 10 must be fastened to wall with suitable fasteners to support intended equipment weight

